

Technical Report 1711068A

24th November 2017

FAO: Lucy Porter, PPSS Ltd
 Unit 1
 Whitfield Buisness Park
 Manse Lane
 Knaresborough
 North Yorkshire
 HB5 8BS

Sample supplied: Grey Cut-Tex ® PRO fabric, which was tested for:

1. Cut resistance according to BS EN ISO 13997:1999.

The sample, in an unused state, was tested between 22rd – 24th November 2017. Testing took place within the Polyco Healthline Technology Centre, South Fen Road, Bourne, PE10 0DN only. The sample was tested as received.

The following results relate only to the sample item tested by the Polyco Healthline Technology Centre.

Written by: Helen Bristow – Laboratory Scientist

Conclusion:

Sample	Performance Level
Grey Cut-Tex ® PRO fabric	5

Test Procedure

TP004 Measurement of cut resistance according to BS EN ISO 13997:1999.

BS EN ISO 13997:1999 Requirements

	Level 4	Level 5
Cutting load	>13 N	>22 N

Authorised by:
Ben Killick - Laboratory Scientist

Technical Report 1711068

Sample name and photograph

Grey Cut-Tex® PRO fabric TAR 1711068



Samples were conditioned for 24 hours at $23 \pm 2^{\circ}\text{C}$ and $50 \pm 5\% \text{RH}$ as required by the test procedure.

Authorised by:

Ben Killick – Laboratory Scientist


Technical Report 1711068

Results - BS EN ISO 13997:1999 Cut resistance

Blade correction factor = 0.95

Mass (g)	Force (N)	Distance (mm)	Corrected distance (mm)
1184.90	23.25	18.09	17.19
1184.90	23.25	32.95	31.30
1184.90	23.25	14.06	13.36
1184.90	23.25	37.16	35.30
1184.90	23.25	21.17	20.11
1485.20	29.14	27.65	26.27
1485.20	29.14	10.67	10.14
1485.20	29.14	23.40	22.23
1485.20	29.14	18.19	17.28
1485.20	29.14	18.64	17.71
1485.20	29.14	18.86	17.92
1685.46	33.07	7.56	7.18
1685.46	33.07	11.02	10.47
1685.46	33.07	8.06	7.66
998.90	19.60	18.61	17.68
899.79	17.65	44.90	42.66
899.79	17.65	44.15	41.94
899.79	17.65	50.00	47.50

First prediction - Corrected distance Vs Force



Authorised by:

Ben Killick – Laboratory Scientist


Technical Report 1711068

Prediction of force required to cut through the sample in a 20 mm cutting stroke = **27.1 N**

Data using the 27.1 N prediction:

Mass (g)	Force (N)	Distance (mm)	Corrected distance (mm)
1378.62	27.05	14.89	14.15
1378.62	27.05	12.56	11.93
1378.62	27.05	27.56	26.18
1378.62	27.05	17.93	17.03
1378.62	27.05	20.80	19.76

Final Prediction - Corrected distance Vs Force



Final prediction of force required to cut through the sample in a 20 mm cutting stroke = **26.4 N**

Performance level: 5

***** END OF REPORT *****

Authorised by:

Ben Killick – Laboratory Scientist